

WISH

Items Detail



02P01S
FLAT PLATE
13 cm. (5")

02P01N
FLAT PLATE
16 cm. (6.25")

02P02S
FLAT PLATE
19 cm. (7.25")

02P02N
FLAT PLATE
21 cm. (8.25")

02P03N
FLAT PLATE
23 cm. (9")



02P22N
FLAT PLATTER
31 cm. (12")

02P04L
FLAT PLATE
29 cm. (11.25")

02P04N
FLAT PLATE
27 cm. (10.5")

02P03L
FLAT PLATE
25 cm. (9.75")



02Z14S
BOWL STACKABLE
10.5 cm. (4")



02Z14N
BOWL STACKABLE
12 cm.. (4.5")



02Z14L
BOWL STACKABLE
13.5 cm.. (5.25")



02H20S
BUTTER DISH
7.5 cm. (2.75")



02H20M
BUTTER DISH
8.5 cm. (3.5")



02B18N
SALAD BOWL
21 cm. (8.25")



02B07N
BOWL
15 cm. (5.75")



02B14N
BOWL
12 cm. (4.5")



02B14S
BOWL
10.5 cm. (4")



02B20N
BOWL
9 cm. (3.5")



02P43N
DEEP PLATE
30 cm. (12")

02D04N
DEEP PLATE
27 cm. (10.5")

02D03N
DEEP PLATE
23 cm. (9")



02Z01N
FLAT PLATE
WITH WIDE SPACE
16 cm. (6.25")

02Z02N
FLAT PLATE
WITH WIDE SPACE
21 cm. (8.25")

02Z03N
FLAT PLATE
WITH WIDE SPACE
23 cm. (9")

02Z03L
FLAT PLATE
WITH WIDE SPACE
25 cm. (9.75")

02Z04N
FLAT PLATE
WITH WIDE SPACE
27 cm. (10.5")

02Z22N
FLAT PLATE
WITH WIDE SPACE
31 cm. (12")



02P21L
OVAL PLATTER
28 cm. X 34 cm.
(10" X 13.5")

02P21M
OVAL PLATE
22.5 cm. X 28 cm.
(8.75" X 11")

02P21S
OVAL PLATE
17 cm. X 21.5 cm.
(6.5" X 8.25")



WISH

Items Detail



02C27N
AD CUP
100 cc. (3 Oz.)

02S28N
AD SAUCER
12.5 cm. (5")



02C05M
COFFEE CUP
200 cc. (6.5 Oz.)

02S06N
SAUCER
15.5 cm. (6")



02C05L
COFFEE CUP
250 cc. (8 Oz.)

02S06N
SAUCER
15.5 cm. (6")



02Z27N
AD CUP STACKABLE
100 cc. (3 Oz.)

02S28N
AD SAUCER
12.5 cm. (5")



02Z05M
COFFEE CUP STACKABLE
200 cc. (6.5 Oz.)

02S06N
SAUCER
15.5 cm. (6")



02Z05L
COFFEE CUP STACK
250 cc. (8 Oz.)

02S06N
SAUCER
15.5 cm. (6")



02C12N
SOUP CUP
280 cc. (9 Oz.)

02S06N
SAUCER
15.5 cm. (6")



02Z12N
SOUP CUP STACKABLE
280 cc. (9 Oz.)

02S06N
SAUCER
15.5 cm. (6")



02M48N
MUG
250 cc. (8 Oz.)



02M23N
MUG
300 cc. (10 Oz.)



02Z48N
MUG STACKABLE
250 cc. (8 Oz.)



02Z23N
MUG STACKABLE
300 cc. (10 Oz.)



02H00S
COFFEE POT W/LID
350 cc. (11.5 Oz.)



02H00L
COFFEE POT W/LID
700 cc. (23 Oz.)



02H08L
TEA POT W/LID
650 cc. (21.5 Oz.)



02H08S
TEA POT W/LID
400 cc. (13 Oz.)



02H10N
CREAMER
300 cc. (10 Oz.)



02H10S
CREAMER
150 cc. (5 Oz.)



02H09N
SUGAR BOWL
300 cc. (10 Oz.)



02H15N
GRAVY BOAT
425 cc. (14 Oz.)



02H25N
SHAKER 1 HOLE



02H24N
SHAKER 3 HOLES



02E19N
EGG CUP
12 cm. (4.75")