

NEO PLUS

Items Detail



03A22N
MOON – FLAT PLATTER
31 cm. (12")



03A04N
MOON – FLAT PLATE
27 cm. (10.5")



03A02N
MOON – FLAT PLATE
21 cm. (8.25")



03A01N
MOON – FLAT PLATE
16 cm. (6.25")



03A05M
MOON – COFFEE CUP
200 cc. (6.5 Oz.)



03A27N
MOON – AD CUP
100 cc. (3 Oz.)



03A88N
MOON – DEEP PLATE
23 cm. (9")



03A90N
MOON – DEEP PLATE
27 cm. (10.5")

03A06N
MOON – SAUCER
15.5 cm. (6")

03A28N
MOON – AD SAUCER
12.5 cm. (4.75")



03W01N
VOGUE – FLAT PLATE
16 cm. (6.25")



03W02N
VOGUE – FLAT PLATE
21 cm. (8.25")



03W03N
VOGUE – FLAT PLATE
23 cm. (9")



03W04N
VOGUE – FLAT PLATE
27 cm. (10.5")



03W04L
VOGUE – FLAT PLATE
29 cm. (11.25")



03W22N
VOGUE – FLAT PLATTER
31 cm. (12")



03W27N
VOGUE – AD CUP
100 cc. (3 Oz.)

03W28N
VOGUE – AD SAUCER
12.5 cm. (4.75")



03W90N
VOGUE – DEEP PLATE
27 cm. (10.5")



03W88N
VOGUE – DEEP PLATE
23 cm. (9")



03W05M
VOGUE – COFFEE CUP
200 cc. (6.5 Oz.)

03W06N
VOGUE – SAUCER
15.5 cm. (6")

03H251
SHAKER 1 HOLE V.1

03H252
SHAKER 1 HOLE V.2



03H24N
SHAKER 3 HOLES

03H24N
SHAKER 3 HOLES



03N01N
BEAT – SQUARE PLATE
16 cm. X 16 cm. (6.25" X 6.25")



03N02N
BEAT – SQUARE PLATE
20 cm. X 20 cm. (7.75" X 7.75")



03N27N
BEAT – AD CUP
100 cc. (3 Oz.)



03N05M
BEAT – COFFEE CUP
200 cc. (6.5 Oz.)

03N04N
BEAT – SQUARE PLATE
27.5 cm. X 27.5 cm.
(10.75" X 10.75")

03N28N
BEAT – AD SAUCER
12.5 cm. (4.75")

03N06N
BEAT – SAUCER
15.5 cm. (6")



03J01N
JOY – FLAT PLATE
16 cm. (6.25")



03J02N
JOY – FLAT PLATE
21 cm. (8.25")



03J88N
JOY – DEEP PLATE
23 cm. (9")



03J22N
JOY – FLAT PLATTER
30 cm. (11.75")



03S092
LID of SUGAR BOWL
200 cc. V.2



03S091
LID of SUGAR BOWL
200 cc. V.1

03H09S
SUGAR BOWL
200 cc. (6.5 Oz.)

03H09S
SUGAR BOWL
200 cc. (6.5 Oz.)



03J05M
JOY – COFFEE CUP
200 cc. (6.5 Oz.)



03J27N
JOY – AD CUP
100 cc. (3 Oz.)

03J06N
JOY – SAUCER
15.5 cm. (6")

03J28N
JOY – AD SAUCER
12.5 cm. (4.75")



03S002
LID of COFFEE POT
400 cc. V.2



03S001
LID of COFFEE POT
400 cc. V.1

03H00S
COFFEE POT
400 cc. (13 Oz.)

03H00S
COFFEE POT
400 cc. (13 Oz.)



03E19N
EGG CUP
12 cm. (4.5")



03L002
LID of COFFEE POT
700 cc. V.2



03L001
LID of COFFEE POT
700 cc. V.1

03H00L
COFFEE POT
700 cc. (23 Oz.)

03H00L
COFFEE POT
700 cc. (23 Oz.)



03H10N
CREAMER
280 cc. (9 Oz.)



03H10S
CREAMER
150 cc. (5 Oz.)



NEO PLUS

Items Detail



03L43C
COVER FOR
PASTA PLATE WITH WIDE RIM



03L43X
COVER FOR
DEEP WIDE RIM PLATE



03W43C
PASTA PLATE WITH WIDE RIM
31 cm. (12")



03W43X
DEEP WIDE RIM PLATE
31 cm. (12")



03E27N
FAME - AD CUP
100 cc. (3 Oz.)

03E28N
FAME - AD SAUCER
12.5 cm. (4.75")



03E05M
FAME - COFFEE CUP
200 cc. (6.5 Oz.)

03E06N
FAME - SAUCER
15.5 cm. (6")




03E88N
FAME - DEEP PLATE
23 cm. (9")



03E03L
FAME - FLAT PLATE
25 cm. (9.75")



03E04L
FAME - FLAT PLATE
29 cm. (11.25")




03Q68L
RECTANGULAR PLATE
20 cm. X 32 cm. (7.85" X 12.5")



03Q04N
SQUARE PLATE
27 cm. X 27 cm. (10.65" X 10.65")



03Q02N
SQUARE PLATE
21 cm. X 21 cm. (8.25" X 8.25")



03Q68M
RECTANGULAR PLATE
15 cm. X 27 cm. (5.9" X 10.65")



03Q01N
SQUARE PLATE
16 cm. X 16 cm. (6.25" X 6.25")