

SIMPLE PLUS

Items Detail



06P22N
FLAT PLATTER
31 cm. (12")

06P04N
FLAT PLATE
27 cm. (10.5")

06P03L
FLAT PLATE
25 cm. (9.75")

06P03N
FLAT PLATE
23 cm. (9")

06P02N
FLAT PLATE
21 cm. (8.25")

06P01N
FLAT PLATE
16 cm. (6.25")



06P43N
DEEP PLATE
30 cm. (11.75")



06D04N
DEEP PLATE
27 cm. (10.5")



06D03N
DEEP PLATE
23 cm. (9")



06P21L
OVAL PLATE
27.5 cm. X 34 cm.
(10.75" X 13.25")

06P21M
OVAL PLATE
22.5 cm. X 28 cm.
(8.75" X 11")

06P21S
OVAL PLATE
18 cm. X 12 cm.
(7" X 8.5")




06P68S
RECTANGULAR PLATTER
14.5 cm. X 22 cm.
(5.5" X 8.5")

06P68M
RECTANGULAR PLATTER
18.5 cm. X 25.5 cm.
(7.25" X 10")

06P68L
RECTANGULAR PLATTER
22.5 cm. X 30.5 cm.
(8.75" X 12")




06C01N
ROUND COUP PLATE
16 cm. (6.25")




06C02N
ROUND COUP PLATE
21 cm. (8.25")




06C03N
ROUND COUP PLATE
23.5 cm. (9.25")



06C03L
ROUND COUP PLATE
25.5 cm. (10")



06C04N
ROUND COUP PLATE
27 cm. (10.5")



06C22N
ROUND COUP PLATTER
31 cm. (12")



06Q01N
SQUARE PLATE
16 cm. X 16 cm.
(6.25" X 6.25")



06Q02N
SQUARE PLATE
21 cm. X 21 cm.
(8.25" X 8.25")



06Q04N
SQUARE PLATE
26.5 cm. X 26.5 cm.
(10.5" X 10.5")



06Q22N
SQUARE PLATE
30 cm. X 30 cm.
(11.75" X 11.75")

SIMPLE PLUS

Items Detail



06D02N
DEEP DISH
21 cm. (8.25")



06D02S
DEEP DISH
19 cm. (7.5")



06D01N
FRUIT BOWL
17 cm. (6.75")



06B14S
BOWL
9 cm. (3.5")



06B14N
RICE BOWL
11 cm. (4.25")



06B07N
SOUP BOWL
15 cm. (5.75")



06M35L
LATTE MUG
450 cc. (15 Oz.)



06M35N
LATTE MUG
350 cc. (12 Oz.)



06Z23N
MUG STACKABLE
300 cc. (10 Oz.)



06Z48N
MUG STACKABLE
250 cc. (8 Oz.)



06Z14S
BOWL STACKABLE
10.5 cm. (4")



06Z14N
BOWL STACKABLE
12 cm. (4.5")



06Z05L
COFFEE CUP STACKABLE
250 cc. (8 Oz.)



06Z05M
COFFEE CUP STACKABLE
200 cc. (6.5 Oz.)



06Z27N
AD CUP STACKABLE
100 cc. (3 Oz.)



06C27H
AD CUP
100 cc. (3 Oz.)



06C27N
AD CUP
100 cc. (3 Oz.)



06C05M
COFFEE CUP
200 cc. (6.5 Oz.)

06S06N
SAUCER
15.5 cm. (6")

06S06N
SAUCER
15.5 cm. (6")

06S28N
AD SAUCER
12.5 cm. (4.75")

06S28N
AD SAUCER
12.5 cm. (4.75")

06S28N
AD SAUCER
12.5 cm. (4.75")

06S06N
SAUCER
15.5 cm. (6")



06H94N
VASE
14 cm. (5.25")



06H89N
SUGAR PACK HOLDER
6.5 cm. X 9 cm. X 5 cm.
(2.5" X 3.5" X 2")



06Z12N
SOUP CUP STACKABLE
280 cc. (9 Oz.)



06C27H
AD CUP
100 cc. (3 Oz.)



06C27N
AD CUP
100 cc. (3 Oz.)



06C05M
COFFEE CUP
200 cc. (6.5 Oz.)

06S06N
SAUCER
15.5 cm. (6")

06Q28N
SQUARE AD SAUCER
12.5 cm. x 12.5 cm.
(4.75" x 4.75")

06Q28N
SQUARE AD SAUCER
12.5 cm. x 12.5 cm.
(4.75" x 4.75")

06Q06N
SQUARE SAUCER
16 cm. x 16 cm.
(6.25" x 6.25")



06H15N
GRAVY BOAT
350 cc. (11.5 Oz.)



06H15S
GRAVY BOAT
200 cc. (6.5 Oz.)



06H09S
SUGAR BOWL
200 cc. (6.5 Oz.)



06H10S
CREAMER
150 cc. (5 Oz.)



06H10N
CREAMER
280 cc. (9 Oz.)



06H00S
COFFEE POT W/LID
450 cc. (15 Oz.)



06H93N
ASHTRAY
9 cm. (3.5")



06H87N
TOOTHPICK HOLDER
4 cm. (1.5")



06E19N
EGG CUP
12 cm. (4.75")



06H24N
SHAKER 3 HOLES



06H25N
SHAKER 1 HOLE